

STANDARD OPERATING PROCEDURE HYPERKEWL COOLING VEST



Hyperkewl Cooling Vest 6529



STEP 1

Wet the cooling vest under tap water, ensuring that both sides are completely soaked.



STEP 2

Gently squeeze the vest with your hands to remove excess water.



STEP 3

After Squeeze, keep the jacket hanging in hand for 1 minute (to enable to remove droplets in inner side).



STEP 4

Wear the jacket.



Hyperkewl Cooling Vest 6550



STEP 1

Wet the cooling vest under tap water, ensuring that both sides are completely soaked.



STEP 2

Gently squeeze the vest with your hands to remove excess water.



STEP 3

After Squeeze, keep the jacket hanging in hand for 1 minute (to enable to remove droplets in inner side).



STEP 4

Wear the jacket.

Distributed by:

SAURYA HSE PVT LTD

C-112A, Kailash Business Park, Veer Sawarkar Marg, Vikhroli (West), Mumbai - 400079, Maharashtra, India

T: +91 22 4065 5555 | E: info@sauryahse.com | W: www.sauryahse.com

Please Note:

- When soaking a vest in a water container/bucket, it is recommended to use disinfectant (Dettol) in water to maintain proper sanitation standards.
- After prolonged use, wash with detergent.