

100% made in Germany

Anleitung | User Guide



Ø 4,8 - 7,5 mm | 3/16" - 19/64"

Coax-Entmanteler Coaxial Cable Stripper Coaxi No. 1 | No. 30600

 Coaxial – Abisolierer für einfaches und schnelles Abisolieren aller gängigen Coaxial-Kabel, z.B. TV-Antennenkabel 4,8-7,5mm Ø, sowie PVC-Rundkabel 3x0,75mm².


 Coaxial cable stripper for quick and easy stripping of most common coaxial cables types e.g. TV-antenna cables types 4,8-7,5mm Ø and 3x0,75mm² round PVC sheathed cable.



A

 Sperre (A) lösen und Werkzeug öffnen

 Release the catch (A) and open the tool.



A

 Kabel bis zur gewünschten Länge (Skalierung innen 5-20mm) in Klinge (Kopfmarkierung ❶) einlegen, Werkzeug schließen, Außenmantel einschneiden mit ¼ Drehung links und rechts und abziehen.

Abschirmung zurückstreifen und mit Klinge (Kopfmarkierung ❷) Innenisolation einschneiden, ¼ Drehung rechts und links – und abziehen. Fertig!

 Insert cable at requested stripping length (scale 5-20 mm inside) into stripping blades (headmarking ❶), cut sheathing by turning closed tool 1 quarter to the right and left, pull sheathing off.

Peel back the shielding and cut into the inner insulation with blade (headmarking ❷). Rotate tool ¼ turn to the right and to the left. Finished!



 **Warnhinweis: Nicht für Arbeiten an oder in der Nähe unter elektrischer Spannung stehender Teile!**

 **Warning: Never use tool on or near live electrical circuits!**