

STANDARD OPERATING PROCEDURE CS3000 NED PERSONNEL CLEANING STATION

Operating Instructions



CS3000 NED Personnel Cleaning Station

Please Note:

- These specifications refer to compressed air volume, not pressure; the recommended operating pressure for the PCS is 80-120 psi
- Do not loosen latches and remove the canister while unit is mounted on the mounting plate.
- Always wear eye and ear protection when operating this unit. Avoid bare skin. Do not use on the face including around the eyes, nose, mouth, or ears.
- The Cartridge Filter will need cleaning or replacement when dirty.

Distributed by:

SAURYA HSE PVT LTD

C-112A, Kailash Business Park, Veer Sawarkar Marg, Vikhroli (West),
Mumbai - 400079, Maharashtra, India

T: +91 22 4065 5555 | E: info@sauryahse.com | W: www.sauryahse.com



STEP 1

Ensure the device is mounted securely, the airline is connected, and the shut-off valve is turned "On" for continuous vacuum operation.



STEP 2

Use the air-agitator brush attachment to remove particles from clothing or skin.



STEP 3

For stubborn debris, activate the air agitator by pressing the lever, which directs a jet of compressed air to lift particles, enabling the vacuum to capture them.



STEP 4

Turn the shut-off valve to the "Off" position to stop the vacuum when cleaning is complete.

Emptying the Collection Canister



STEP 1

Ensure the shut-off valve is in the "Off" position & disconnect the compressed air line.



STEP 2

Unfasten the latches and lift the vacuum head from the canister.



STEP 3

Empty the debris into an appropriate waste container. If liquid is present, loosen the drain valve and pour the liquid into a suitable container.



STEP 4

Reattach the vacuum head & reinstall on the mounting plate.